

Smart POD Electrode assembly instructions

The following explanation describes how to assemble the electrodes, after they were disassembled before shipment, as the electrodes must be within water and water may freeze during shipment and damage the electrodes.

1. **Make sure that no power and no water are connected.**
2. Remove the yellow protective cover.



3. Insert the electrode into the right large hole in the acrylic cell



4. Close the electrode cup thread clockwise using a screwdriver



5. Take the PH electrode and insert it to the left small hole.



6. Close the electrode cup thread clockwise using a screwdriver



7. Connect the PH electrode cable to the PH electrode and close it well



8. Connect water inlet and turn on the power. Verify that there are no water leaks through the electrode connections. If water leaks, strengthen the electrode connections using a screwdriver.